


LandAirSea Tracking Key Features



#	Feature	Comments
1	USB Plug	Remove protective cap to expose USB plug.
2	Internal GPS Antenna	
3	Battery Indicator	Green = Batteries are good Red = Batteries are in need of replacement
4	GPS Indicator	Flashing Green Light = GPS Lock No Light = No GPS lock
5	Magnetic Mount	
6	Battery Cover Mounting Screws	Unscrew to remove battery cover.
7	Battery Cover	Remove to replace batteries.

NOTE 1: There is no on/off switch on the LandAirSea Tracking Key. Once you place batteries in the unit the system will be on and ready to track. For long storage periods it is recommended that you remove the batteries from your unit. Otherwise after 3 minutes your system will go into a low power sleep mode.

NOTE 2: There is a motion sensor inside the Tracking Key. If you shake the device you will hear it vibrate. This is normal.